

Blue My Mind Operating Instructions

SKU 3419



ATHENA'S
HOME NOVELTIES

This new toy blew the minds of our research committee. The ergonomically designed rigid, silicone covered shaft is slightly curved like many of its counterparts in this category. However, this is no ordinary vibe! The tip contains out-of-this-world, 3-speed, G-spot thumping, pulsating power for internal sensations you've never felt before! The 10 function, flexible, flickering, external stimulator teases and tantalizes with some of the strongest vibration you'll ever encounter! The sleek 3-button control pad lets you independently operate the vibration and thumping options. The high-tech memory chip remembers just how you like it and will resume on the last function used. Your mind will be blown in and out of the bath or shower too!

Features :

- Rechargeable - charge conveniently with the USB cable included
- Charge time: 2.5 hours
- Run time: .70 hour on highest settings
- Run time: 2.5 on low settings
- State-of-the-art memory chip resumes on last function used
- 3 speeds of independent shaft vibration
- 10 functions of independent vibration, pulsation and escalation in the stimulator
- Security travel lock feature
- Length: 8"
- Insertable length: 4.25"
- Width: 1.5"
- Silicone with ABS plastic on handle
- Latex and Phthalate free
- Not for use with silicone lubricants
- Waterproof
- Provides G-spot stimulation

Internal Shaft

Flickering External Clitoral Teaser

Control Panel



Cleaning

Always clean product before first use, and clean after every use.

For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer SKU 5701. Not for use with silicone lubricants.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat.

Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces.

Place them on a cloth to protect your toys and your furniture.

Warranty

All sales are final due to the intimate nature of our products. Motorized products are guaranteed for 30 days for a replacement. No refunds will be given. If you receive a broken product, or if your product breaks within 30 days of receipt, please contact your distributor, if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to send back your item for a replacement. All defective product returns must be accompanied by a pre-authorization number.

Our Customer Care Liaison can be reached by calling (877) ATHENAS or via email at E-mail: customerservice@athenashn.com



ATHENA'S
HOME NOVELTIES

www.athenashn.com

January ©2019 Athena's Home Novelties, Inc.
640 Winter Street Woonsocket RI 02895 1-877-ATHENAS

Charging

Charge upon opening. Insert input plug at the back toward the base and connect the USB output plug to the USB port of your computer or other power source and the other end to the toy's input.

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.


Complete charge time: 2.5 hours

Run time on high: .70 hour

Run time on low: 2.5 hours



Control Panel



Operating:

1. This item comes with a security lock feature. To unlock product, press and hold the top button for 3 seconds.
2. To activate special shaft feature, press the middle button. Tap the button until desired function is reached.
3. To turn off special shaft feature at any time, press and hold the middle button for 3 seconds.
4. To activate vibrating functions in the stimulator, press the bottom button once. Tap the button until desired function is reached.
5. To turn off vibrations in the stimulator at any time, press and hold the bottom button for 3 seconds.
6. To turn off all special shaft features and vibrations in the stimulator at any time, press the top button once.
7. To relock product, repeat step 1. Ensure product is locked after each use to conserve battery life.