

Masseuse Operating Instructions

SKU 3418



Having your own personal Masseuse will reduce stress levels and bring you more pleasure! This ultra-powerful cordless massager is simple, ergonomic and easy to operate. The rounded soft-touch head is coated with silky smooth silicone and mounted on a bendable neck. A premium motor provides 28 functions of exceptional power to relieve your aching muscles and tension. This deeply satisfying wand can be used for all over body massage in and out of water. Storage pouch included. Phthalate free.

Features :

- Rechargeable - charge conveniently with the USB cable or with prong wall adaptor, both are included
- Charge: 1 hour
- Run time low: about 5 hours
- Run time high: about 3 hours
- 20 waves of pulsation
- 8 speeds of vibration
- Length: 12"
- Head width: 2.5"
- Shuts off automatically after 5 minutes of no use
- Silicone with ABS plastic detail
- Phthalate free
- Not for use with silicone lubricants
- Waterproof



Cleaning

Always clean product before using and clean again after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Lubrication

Be sure to use ample lubrication with your massager for maximum comfort and enjoyment. For great results try Athena's Perfectly Pure Intimate Moisturizer SKU 5701, Skinny Dip Massage Lotion SKU 5008 or any of our luxury massage oils or lotions. Not for use with silicone lubricants or lotions.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat.

Store in a cool, dry location.

Store products separately as different materials may react with each other.

Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces.

Place them on a cloth to protect your toys and your furniture.

Caution

This massager is not classified as a medical device. Do not massage around chest or neck. Do not attempt to use while plugged in for charging. Gently (to protect waterproofed seal) insert input plug at the back of the wand.

Warranty

All sales are final due to the intimate nature of our products. Motorized products are guaranteed for 30 days for a replacement. No refunds will be given. If you receive a broken product, or if your product breaks within 30 days of receipt, please contact your distributor, if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to send back your item for a replacement. All defective product returns must be accompanied by a pre-authorization number.

Our Customer Care Liaison can be reached by calling (877) ATHENAS or via email at E-mail: customerservice@athenashn.com




January ©2019 Athena's Home Novelties, Inc.
640 Winter Street Woonsocket RI 02895 1-877-ATHENAS


Charging

Charger arrives about 50% charged. You do not need to charge upon opening. Gently (to protect waterproofed seal) insert input plug at the back of the wand and connect the USB output plug to the USB port of your computer or other power source. Or insert USB into wall plug adaptor and plug the AC adapter power cord directly into a functioning wall outlet. The LED light will flash when charging and remain solid when fully charged.

- Charge: 1 hour
- Run time low: about 5 hours
- Run time high: about 3 hours



Control Panel



Operating:

Turn On by tapping the power button. The light will turn on. Turn Off by tapping the power button.

Tap the middle button to circulate through the 20 pulsation waves.

Tap the top button to circulate through the 8 speeds of vibration.