

Social Butterfly Operating Instructions



SKU 3433



Experience the thrill of glow-in-the-dark play with this eye-catching, dual vibe! Not only will it light up your night, your pleasure centers will ignite. The rigid, multi-chrome shaft is constructed of a sleek body safe ABS plastic. The smooth rounded tip firmly presses on the G-Spot. The large, flexible silicone butterfly shaped stimulator lands externally with antennae and wings that buzz. 2 motors provide 10 functions and speeds for your orgasmic delight. Easy to use ergonomic controls make switching speeds a breeze! Imagine the wet and wild light show in your bubble bath or shower!

Features :

Silicone and ABS Plastic
 Provides G-spot stimulation
 Not for use with silicone lubricants
 Waterproof
 Phthalate free and Latex free
 Length: 7.75 inches
 Insertable length: 4.75
 Width: 1.5 inches at widest point

Rechargeable: USB charge cord included
 Complete charge: 2 hours
 Run time high speed: 1.5 hours
 Run time low speed: 2 hours



Operating

ON/OFF/Vibrate: Press the bottom On/Off button for 3 seconds to start and initiate the 1st speed, press for 3 seconds to stop. The button will glow when On.

Vibration and Pulsation: Tap the top button to adjust speed and cycle through the other 9 functions.



Cleaning and storage

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)
 Store in a cool dry location.

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog. Do not use this vibe with silicone lubricants.

Follow these simple steps to help extend the life cycle of your items

- Do not store products near extreme cold or heat.
- Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.
- Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Warranty

All sales are final due to the intimate nature of our products. Motorized products are guaranteed for 30 days for a replacement. No refunds will be given. If you receive a broken product, or if your product breaks within 30 days of receipt, please contact your distributor, if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to send back your item for a replacement. All defective product returns must be accompanied by a pre-authorization number.

Our Customer Care Liaison can be reached by calling (877) ATHENAS or via email at E-mail: customerservice@athenashn.com



www.athenashn.com

May ©2019 Athena's Home Novelties, Inc.
 640 Winter Street, Woonsocket, RI 02895 1-877-ATHENAS

Charging

Charging

Comes 60% (partially) charged. No need to charge before first use. Connect the USB cable to the USB port of your computer or other power source and connect the other end to the toys charging port.

The LED light will blink when charging and become solid when fully charged. Vibrations slow as charge is depleted. There is no danger of battery damage by overcharging, but we recommend to not over charge for long periods of time.

Rechargeable: USB charge cord included
 Complete charge: 2 hours
 Run time high speed: 1.5 hours
 Run time low speed: 2 hours

